



Open browser and enter the following

URL: <http://192.168.100.1>

- Username: root
- Password: admin

افتح المتصفح وقم بالدخول على صفحة اعدادات الجهاز

من خلال الرابط التالي : <http://192.168.100.1>

اسم المستخدم : root
كلمة المرور : admin





- بعد تسجيل الدخول ستظهر الصفحة الرئيسية للمودم, اختر WLAN.

 **HG8245T** Logout

Status WAN LAN IPv6 **WLAN** Security Route Forward Rules Network Application Voice System Tools

WLAN Configuration WLAN > WLAN Configuration

On this page, you can set the WLAN parameters, including the WLAN switch, SSID configuration and channel selection.

☒ Enable WLAN

Basic Configuration New Delete

	SSID Index	SSID Name	SSID State	Associated Device Number	Broadcast SSID	Security Configuration
☐	1	WirelessNet	Enable	32	Enable	Unconfigured

SSID Configuration in Detail

SSID Name:

WirelessNet

*(1-32 characters)

Enable SSID:

☒

Associated Device Number:

32

*(1-32)

Broadcast SSID:

☒

WMM Enable:

☒

Authentication Mode:

WPA/WPA2 Pre-Share

Encryption Mode:

TKIP&AES

WPA PreSharedKey:

••••••••

☒ Hide *(8-63 ASCII characters or 64 hexadecimal digits)

WPA Group Rekey Interval:

3600

*s(600-86400)

WPS Enable:

☐

WPS Mode:

PBC

PBC:

WPS Start

Apply Cancel

• اتباع التعليمات كما هو موضح بالصورة التالية :

HG8245T Logout

Status WAN LAN IPv6 **WLAN** Security Route Forward Rules Network Application Voice System Tools

WLAN Configuration WLAN > WLAN Configuration

On this page, you can set the WLAN parameters, including the WLAN switch, SSID configuration and channel selection.

☒ Enable WLAN → 1- تفعيل وتعطيل الواي فاي

Basic Configuration New Delete

SSID Index	SSID Name	SSID State	Associated Device Number	Broadcast SSID	Security Configuration
☐ 1	WirelessNet	Enable	32	Enable	Unconfigured

SSID Configuration in Detail

SSID Name: * (1-32 characters) → 2- يمكن تغيير اسم شبكة الواي فاي.

Enable SSID: ☒

Associated Device Number: * (1-32)

Broadcast SSID: ☒

WMM Enable: ☒

Authentication Mode: → 3- اختر نوع التشفير كما هو محدد.

Encryption Mode:

WPA PreSharedKey: ☒ Hide * (8-63 ASCII characters or 64 hexadecimal digits) → 4- يرجى ادخال كلمة المرور حيث انها لا تقل عن 8 أرقام او حروف.

WPA Group Rekey Interval: *s(600-86400)

WPS Enable: ☐

WPS Mode:

PBC:

5- ← للتحفظ Apply.

بعد حفظ الاعدادات سيتم فصل الجهاز عن شبكة الواي فاي ويجب اعادة البحث عن اسم الشبكة واعادة الاتصال مع المعلومات الجديدة.